

<b>Manufacturer</b>	<b>Model</b>	<b>Connector</b>
Acer	beTouch E110	microUSB
Acer	beTouch E120	microUSB
Acer	beTouch E130	microUSB
Acer	beTouch E140	microUSB
Acer	beTouch E210	microUSB
Acer	beTouch E400	microUSB
Acer	Iconia Smart	microUSB
Acer	Liquid Metal	microUSB
Acer	neoTouch P300	microUSB
Acer	neoTouch P400	microUSB
Acer	Stream	microUSB
Apple	iPhone	Apple
Apple	iPhone 3G	Apple
Apple	iPhone 3GS	Apple
Apple	iPhone 4	Apple
Blackberry	Apollo	microUSB
Blackberry	Bold 9650	microUSB
Blackberry	Bold 9700	microUSB
Blackberry	Bold 9780	microUSB
Blackberry	Curve 3G 9330	microUSB
Blackberry	Curve 8520	microUSB
Blackberry	Curve 8900	microUSB
Blackberry	Curve 9220	microUSB
Blackberry	Dakota	microUSB
Blackberry	Monaco	microUSB
Blackberry	Pearl	microUSB
Blackberry	Storm 2	microUSB
Blackberry	Storm 3	microUSB
Blackberry	Storm 9500	microUSB
Blackberry	Storm 9530	microUSB
Blackberry	Torch 2	microUSB
Blackberry	Torch 9800	microUSB
Blackberry	Tour 9630	microUSB
Google	Nexus S	microUSB
Google	Nexus S 4G	microUSB
HP	iPAQ Glisten	microUSB
HP	iPAQ Voice Messenger	microUSB
HP	Pre 3	microUSB
HTC	7 Mozart	microUSB
HTC	7 Trophy	microUSB
HTC	Aria	microUSB
HTC	ChaCha	microUSB
HTC	Desire	microUSB
HTC	Desire HD	microUSB
HTC	Desire S	microUSB
HTC	Desire Z	microUSB
HTC	Droid Incredible	microUSB
HTC	Droid Incredible 2	microUSB
HTC	EVO 3D	microUSB
HTC	EVO 4G	microUSB
HTC	Freestyle	microUSB
HTC	Gratia	microUSB

HTC	HD mini	microUSB
HTC	HD2	microUSB
HTC	HD7	microUSB
HTC	HD7S	microUSB
HTC	Hero 2	microUSB
HTC	Ignite	microUSB
HTC	Incredible S	microUSB
HTC	Inspire	microUSB
HTC	Legend	microUSB
HTC	Merge	microUSB
HTC	Prime	microUSB
HTC	Pyramid	microUSB
HTC	Salsa	microUSB
HTC	Surround	microUSB
HTC	Thunderbolt	microUSB
HTC	Wildfire	microUSB
HTC	Wildfire S	microUSB
LG	Bliss	microUSB
LG	C100	microUSB
LG	C305	microUSB
LG	Chocolate Touch	microUSB
LG	Cookie 3G	microUSB
LG	Cookie Fresh	microUSB
LG	Cookie Lite	microUSB
LG	Cookie Style	microUSB
LG	dLite	microUSB
LG	E900h	microUSB
LG	Encore	microUSB
LG	GD900F	microUSB
LG	GM600	microUSB
LG	GM750	microUSB
LG	GS107A	microUSB
LG	GT500	microUSB
LG	GT505	microUSB
LG	GW300	microUSB
LG	GW910	microUSB
LG	GX300	microUSB
LG	KM555	microUSB
LG	KM570	microUSB
LG	Mini	microUSB
LG	New Chocolate BL40	microUSB
LG	New Chocolate BL40G	microUSB
LG	Optimus	microUSB
LG	Optimus 2X	microUSB
LG	Optimus 7	microUSB
LG	Optimus Chic	microUSB
LG	Optimus Me P350	microUSB
LG	Optimus One	microUSB
LG	Optimus S	microUSB
LG	Optimus T	microUSB
LG	P520	microUSB
LG	Pop GD510	microUSB
LG	Prime	microUSB

LG	Revolution	microUSB
LG	Sentio	microUSB
LG	Shine Touch	microUSB
LG	T315i	microUSB
LG	Thrill 4G	microUSB
LG	Town C300	microUSB
LG	Viewty GT	microUSB
LG	Viewty Snap	microUSB
LG	Vortex	microUSB
LG	Vu Plus	microUSB
LG	Cookie Plus	microUSB
LG	GX500	microUSB
LG	Optimus 3D	microUSB
LG	Optimus Black	microUSB
LG	Saber	microUSB
Microsoft	Kin One	microUSB
Microsoft	Kin Two	microUSB
Motorola	Atrix 4G	microUSB
Motorola	Bravo	microUSB
Motorola	Charm	microUSB
Motorola	Citrus	microUSB
Motorola	Cliq 2	microUSB
Motorola	Cliq XT	microUSB
Motorola	Crush	microUSB
Motorola	Defy	microUSB
Motorola	Droid	microUSB
Motorola	Droid 2	microUSB
Motorola	Droid 3	microUSB
Motorola	Droid Bionic	microUSB
Motorola	Droid Pro	microUSB
Motorola	Droid X	microUSB
Motorola	Droid X 2	microUSB
Motorola	Flipside	microUSB
Motorola	i1	microUSB
Motorola	Milestone	microUSB
Motorola	Milestone 2	microUSB
Motorola	Milestone XT720	microUSB
Motorola	Quench	microUSB
Motorola	Targe	microUSB
Nokia	1661	2mm Nokia
Nokia	2690	2mm Nokia
Nokia	3608	2mm Nokia
Nokia	5000	2mm Nokia
Nokia	5030	2mm Nokia
Nokia	5228	2mm Nokia
Nokia	5230	2mm Nokia
Nokia	5230	2mm Nokia
Nokia	5250	2mm Nokia
Nokia	6220	2mm Nokia
Nokia	6260	2mm Nokia
Nokia	6350	microUSB
Nokia	6720	2mm Nokia
Nokia	6760	2mm Nokia

Nokia		7020	2mm	Nokia
Nokia		7020	2mm	Nokia
Nokia		7230	2mm	Nokia
Nokia		7510	2mm	Nokia
Nokia		8208	2mm	Nokia
Nokia	2330	Classic	2mm	Nokia
Nokia	2680	Slide	2mm	Nokia
Nokia	2700	classic	2mm	Nokia
Nokia	2710	Navigation	2mm	Nokia
Nokia	2720	fold	2mm	Nokia
Nokia	2730	classic	2mm	Nokia
Nokia	3110	Classic	2mm	Nokia
Nokia	3600	Slide	2mm	Nokia
Nokia	3610	fold	2mm	Nokia
Nokia	3710	Fold	2mm	Nokia
Nokia	3720	Classic	2mm	Nokia
Nokia	5130	XpressMusic	2mm	Nokia
Nokia	5220	XpressMusic	2mm	Nokia
Nokia	5235	Comes with music	2mm	Nokia
Nokia	5310	XpressMusic	2mm	Nokia
Nokia	5320	XpressMusic	2mm	Nokia
Nokia	5330	Mobile TV Edition	2mm	Nokia
Nokia	5330	XpresssMusic	2mm	Nokia
Nokia	5530	Xpress Music	2mm	Nokia
Nokia	5610	XpressMusic	2mm	Nokia
Nokia	5630	XpressMusic	2mm	Nokia
Nokia	5730	XpressMusic	2mm	Nokia
Nokia	5800	Navigation Edition	2mm	Nokia
Nokia	5800	XpressMusic	2mm	Nokia
Nokia	6110	Navigator	2mm	Nokia
Nokia	6210	Navigator	2mm	Nokia
Nokia	6212	classic	2mm	Nokia
Nokia	6303	classic	2mm	Nokia
Nokia	6303i		2mm	Nokia
Nokia	6500	Classic	microUSB	
Nokia	6500	Slide	2mm	Nokia
Nokia	6600	fold	2mm	Nokia
Nokia	6600	slide	2mm	Nokia
Nokia	6600i	slide	2mm	Nokia
Nokia	6700	classic	2mm	Nokia
Nokia	6700	Slide	2mm	Nokia
Nokia	6710	Navigator	2mm	Nokia
Nokia	6730	Classic	2mm	Nokia
Nokia	6790	Surge	2mm	Nokia
Nokia	7070	Prism	2mm	Nokia
Nokia	7100	Supernova	2mm	Nokia
Nokia	7210	Supernova	2mm	Nokia
Nokia	7310	Supernova	2mm	Nokia
Nokia	7500	Prism	2mm	Nokia
Nokia	7510	Supernova	2mm	Nokia
Nokia	7610	Supernova	2mm	Nokia
Nokia	7900	Prism	2mm	Nokia
Nokia	8800	Arte	microUSB	

Nokia	8800 Carbon Arte	microUSB
Nokia	8800 Gold Arte	microUSB
Nokia	C1-00	2mm Nokia
Nokia	C1-01	2mm Nokia
Nokia	C1-02	2mm Nokia
Nokia	C2-00	2mm Nokia
Nokia	C2-01	2mm Nokia
Nokia	C3-00	2mm Nokia
Nokia	C3-01 Touch and Type	2mm Nokia
Nokia	C5-00	2mm Nokia
Nokia	C5-03	2mm Nokia
Nokia	C6-00	2mm Nokia
Nokia	C6-01	2mm Nokia
Nokia	C7-00	2mm Nokia
Nokia	E5-00	2mm Nokia
Nokia	E51	2mm Nokia
Nokia	E52	microUSB
Nokia	E55	microUSB
Nokia	E6-00	microUSB
Nokia	E61i	2mm Nokia
Nokia	E63	2mm Nokia
Nokia	E65	2mm Nokia
Nokia	E66	2mm Nokia
Nokia	E7-00	microUSB
Nokia	E71	2mm Nokia
Nokia	E72	2mm Nokia
Nokia	E75	2mm Nokia
Nokia	E90 Communicator	2mm Nokia
Nokia	Mural 6750	2mm Nokia
Nokia	N70	2mm Nokia
Nokia	N75	2mm Nokia
Nokia	N77	2mm Nokia
Nokia	N78	2mm Nokia
Nokia	N79	2mm Nokia
Nokia	N8-00	2mm Nokia
Nokia	N80	2mm Nokia
Nokia	N81	2mm Nokia
Nokia	N81 8GB	2mm Nokia
Nokia	N82	2mm Nokia
Nokia	N85	2mm Nokia
Nokia	N86 8MP	2mm Nokia
Nokia	N900	microUSB
Nokia	N95	2mm Nokia
Nokia	N95 8GB	2mm Nokia
Nokia	N96	2mm Nokia
Nokia	N97	microUSB
Nokia	N97 Mini	microUSB
Nokia	X2-00	2mm Nokia
Nokia	X2-01	2mm Nokia
Nokia	X3	2mm Nokia
Nokia	X3-02 Touch and Type	2mm Nokia
Nokia	X6	2mm Nokia
Nokia	X6 16GB	2mm Nokia

Nokia	X6 8GB	2mm Nokia
Palm	Pixi	microUSB
Palm	Pixi Plus	microUSB
Palm	Pre	microUSB
Palm	Pre 2	microUSB
Samsung	Acclaim	microUSB
Samsung	B7722	microUSB
Samsung	Behold 2 SGH-T939	microUSB
Samsung	Captive	microUSB
Samsung	Champ	microUSB
Samsung	Continuum	microUSB
Samsung	Corby 2	microUSB
Samsung	Corby 3G S3370	microUSB
Samsung	Corby Beat M3710	microUSB
Samsung	Craft	microUSB
Samsung	Diva S7070	microUSB
Samsung	E2652 Champ Duos	microUSB
Samsung	Epic 4G	microUSB
Samsung	Eternity 2	microUSB
Samsung	Fascinate	microUSB
Samsung	Flight	microUSB
Samsung	Flight 2	microUSB
Samsung	Focus	microUSB
Samsung	Galaxy	microUSB
Samsung	Galaxy 3	microUSB
Samsung	Galaxy 5	microUSB
Samsung	Galaxy Ace	microUSB
Samsung	Galaxy Fit	microUSB
Samsung	Galaxy Gio	microUSB
Samsung	Galaxy Indulge	microUSB
Samsung	Galaxy Mini	microUSB
Samsung	Galaxy Pro	microUSB
Samsung	Galaxy S	microUSB
Samsung	Galaxy S 2	microUSB
Samsung	Galaxy S 4G	microUSB
Samsung	Galaxy S Plus	microUSB
Samsung	Galaxy SL	microUSB
Samsung	Galaxy Spica	microUSB
Samsung	Gem	microUSB
Samsung	Giorgio Armani Galaxy S	microUSB
Samsung	Gravity T	microUSB
Samsung	I7500L	microUSB
Samsung	I8000L	microUSB
Samsung	I8520 Beam	microUSB
Samsung	I9000B	microUSB
Samsung	Infuse 4G	microUSB
Samsung	Instinct HD	microUSB
Samsung	Intensity 2	microUSB
Samsung	Intercept	microUSB
Samsung	Intrepid	microUSB
Samsung	Jet	microUSB
Samsung	Mythic SGH-A897	microUSB
Samsung	Omnia 2	microUSB

Samsung	Omnia 7	microUSB
Samsung	Omnia Lite B7300	microUSB
Samsung	Omnia Pro 4	microUSB
Samsung	Omnia Pro 5	microUSB
Samsung	Omnia Pro B7330	microUSB
Samsung	Pixon 12	microUSB
Samsung	Reality	microUSB
Samsung	S5530	microUSB
Samsung	S5560	microUSB
Samsung	S5600 Blade	microUSB
Samsung	S5620	microUSB
Samsung	SCH-R860 Caliber	microUSB
Samsung	Seek	microUSB
Samsung	Solstive 2	microUSB
Samsung	Star 2	microUSB
Samsung	Strive	microUSB
Samsung	Suede	microUSB
Samsung	Transform	microUSB
Samsung	Wave	microUSB
Samsung	Wave 2	microUSB
Samsung	Wave 525	microUSB
Samsung	Wave 575	microUSB
Samsung	Wave 578	microUSB
Samsung	Wave 723	microUSB
Samsung	Vibrant	microUSB
Sanyo	Incognito SCP-6760	microUSB
Sanyo	Taho	microUSB
Sony Ericsson	Aspen	microUSB
Sony Ericsson	Naite	microUSB
Sony Ericsson	Vivaz	microUSB
Sony Ericsson	Vivaz Pro	microUSB
Sony Ericsson	X10	microUSB
Sony Ericsson	X8	microUSB
Sony Ericsson	Xperia Arc	microUSB
Sony Ericsson	Xperia Neo	microUSB
Sony Ericsson	Xperia Pro	microUSB
Vertu	Ascent 2010	microUSB
Vertu	Ascent Ti	microUSB
Vertu	Signature S	microUSB



## SUPPORTED TABLETS

<b>Manufacturer</b>	<b>Model</b>	<b>Connector</b>
Acer	Iconia Tab A100	microUSB
Acer	Iconia Tab A500	microUSB
Acer	Iconia Tab A501	microUSB
Asus	Eee Pad MeMo	microUSB
Blackberry	Playbook	microUSB
HP	TouchPad	microUSB
HTC	Evo View 4G	microUSB
HTC	Flyer	microUSB
Huawei	Ideos S7	microUSB
LG	Optimus Pad	microUSB
Motorola	Xoom	microUSB

<b>Manufacturer</b>	<b>Model</b>	<b>Connector</b>
Apple	iPod Classic 6th G 120GB (late 2008)	Apple
Apple	iPod Classic 6th G 160GB	Apple
Apple	iPod Classic 6th G 160GB (late 2009)	Apple
Apple	iPod Classic 6th G 80GB	Apple
Apple	iPod Mini 1st G	Apple
Apple	iPod Mini 2nd G	Apple
Apple	iPod Nano 1st G	Apple
Apple	iPod Nano 2nd G	Apple
Apple	iPod Nano 3rd G	Apple
Apple	iPod Nano 4th G	Apple
Apple	iPod Nano 5th G	Apple
Apple	iPod Nano 6th G	Apple
Apple	iPod Touch 1st G	Apple
Apple	iPod Touch 2nd G	Apple
Apple	iPod Touch 3rd G	Apple
Apple	iPod Touch 4th G	Apple



## SUPPORTED EBOOKS

<b>Manufacturer</b>	<b>Model</b>	<b>Connector</b>
Amazon	2 International	microUSB
Amazon	DX	microUSB
Amazon	DX International	microUSB
Amazon	DX International 2	microUSB
Amazon	Kindle 2	microUSB
Amazon	Kindle 3G	microUSB